

Omix-ADA Factory Style Replacement Fender Flare Rear (97-06 Wrangler TJ)

Driver or passenger side

Installation Time: 30 Minutes

Tools Required:

- ✓ 10 mm socket
- ✓ 8 mm socket
- ✓ Zip / Cable ties
- ✓ Zip / Cable tie cutters

For this installation the Omix-ADA Fender Flare Hardware Kit (97-06 Wrangler TJ) will be used. (Item J12202 MPN# 11603.09) Along with additional M6x18 washers. Some Wrangler TJ's may have inner-fender liners.

Installation Instructions:

1. Before, the factory flares where discolored and chipped.



2. Remove the 10 mm nut from the front lower mounting location



3. Remove 5-6 8mm factory mounting bolts with 8mm nuts. Also cut possible cable ties holding the fender in.





4. The fender should now be free from the jeep. I removed the factory stud style mount. Due to it not allowing the fender to sit flush on the jeep body. 11 mm nut with 11 mm bolt head can be accessed from the hole in the body shown above the nut or from a small access hole below the nut.



5. The Omix-ADA Fender Flare Hardware Kit includes a hex style nut with 8 mm bolts. This matches a mounting location on the Jeep body.



6. When mounting the new fenders line up the mounting tabs



7. The Omix-ADA Fender Flare Hardware Kit includes 8 mm screws with plastic backing nuts



8. Cable ties may have to be used to hold the new fender in place while installing the included screws and backing nuts. I chose to leave the cable ties install permanently.
9. Some of the mounting hose where too large for the screw head to secure the fender. I used additional M6x18 washers.



10. Cable tie locations and provided 8 mm screws with plastic backing nuts



11. Hex nut with 8 mm bolt



12. Installation complete



Installation Instructions Written by ExtremeTerrain Customer T. Boyer 10/15/2017