

Raxiom Grille Mounted 20 in. LED Slim Light Bar
Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Allen Wrench (Supplied)
- ✓ Drill
- ✓ 23/64" Drill Bit
- ✓ 14mm Wrench
- ✓ Trim/Clip Removal Tool

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the light bar and necessary hardware are included and undamaged.



Figure A

2. Disconnect the turn signals inside the engine bay by sliding the red locking tab over and then pressing in the clip (Figure B).



Figure B

3. Raise the hood and remove the six plastic clips connecting the grille to the chassis using a trim/clip removal tool (Figure C) then remove the grille from the chassis.



Figure C

4. Remove the four clips (Figure D) holding the air dam to the radiator support using a trim/clip removal tool.



Figure D

5. Increase the size of the holes where the four clips were using a 23/64" drill bit (Figure E).



Figure E

6. Assemble the rivnut, spacer nut, washer, and allen bolt (Figure F) and install using a 14mm wrench and Allen Wrench (supplied).



Figure F

7. Install the supplied bracket using the Allen bolts and attach the LED Slim Light Bar (Figure G).



Figure G

8. Connect the red eyelet of the wiring harness to the positive (+) terminal of the battery (Figure H) and the black eyelet of the wiring harness to the negative (-) terminal of the battery (Figure I).



Figure H



Figure I

9. Run the wiring harness to the location where the switch will be mounted and connect the wiring harness to the LED Slim Light Bar (Figure J).



Figure J

10. Reinstall the grille and turn signal plugs.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 09/22/2017