

Recon Smoked LED 3rd Brake Light (07-17 Wrangler JK) Installation Guide

Installation Time: 20 Minutes

Tools Required:

- ✓ Socket Wrench
- ✓ T20 Torx Bit

Installation Instructions:

1. Remove the spare tire
2. Remove all 4 torx screws with the T20 torx bit



3. Unclip wiring harness from the factory third brake light



4. Reinstall the wiring harness on the Recon Third Brake light



5. Reinstall all 4 torx screws with the T20 torx bit
6. Reinstall the spare tire.



Installation Instructions Written by ExtremeTerrain Customer Thomas Sandoval 10/10/2017