

Baja Designs LED Dome Light w/ Switch - White
Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife (To Open Packaging)
- ✓ 3mm Allen Wrench
- ✓ Wiring Harness

Installation Instructions:

1. Layout all materials provided and make sure that the light, mount, and mounting hardware are all provided for the Baja Designs LED Dome Light w/Switch (Figure A).



Figure A

2. Place the provided zip tie in the notch of the mount (Figure B).



Figure B

3. Place the LED against the mount with the zip tie still in the notch and run one of the supplied bolts through the one side's hole (Figure C).



Figure C

4. Thread the nut onto the back end (Figure D).



Figure D

5. Screw the bolt in using a 3mm Allen wrench (Figure E).



Figure E

6. Repeat Steps 3-5 on the other side (Figure F).



Figure F

7. Run the negative (black) and positive (red) wires off the LED to a wiring harness (not provided).
8. Mount the LED in the desired position using the zip tie (Figure G).



Figure G



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 06/21/2018