

Barricade Quick Release Textured Black Rectangular Mirrors

Installation Time: 30 Minutes

Tools Required:

- ✓ Jeep supplied tool set and/or T40 torx bit with ratchet
- ✓ 7/16" wrench

Written by Extreme Terrain Customer Jeff J.

Installation Notes, Pre-Installation notes (only when needed)

Installation Instructions

1. Remove the two top pillar screws from windshield using t40 torx bit.
2. Position supplied bracket in place with welded nut down. Tighten using t 40 torx

#1



#2



3. Unpack mirror supplied for assembly. Assemble and tighten the lock washer/nut using 7/16" wrench



4. Position knurled nuckle link on opposite end of mirror assembly.



5. Place knurled link into bracket and tighten by hand securely. Adjust angle of bracket mirror as needed.



6. Finished look.

