

Jeep Wrangler Adventure Side-View Mirrors (Round) (2018 JL)

Installation Time: 1 Hours based on proficiency with tools

Tools Required:

- ✓ Socket Set (13 mm, 15 mm)
- ✓ Jeep Tools (included with vehicle)

This installation was performed on a 2018 JL Jeep Wrangler Sport S

Installation Instructions:

1. Locate your Jeep Tools (provided with Jeep)



2. Next, remove trim panel by placing finger in outlet and pulling directly backwards towards you.



3. Remove door brace bolt with Jeep Tool



4. Disconnect wiring harness for the door by pushing down on the RED clip, then grasping the bottom black clip. This will allow you to push the white brace upwards. Continue pushing upwards until the wiring harness disconnects itself.



5. On the outside of the door, remove the two bolts internal to the mechanism.



6. Securely store door jamb bolt and the two exterior bolts in the back of the vehicle under the cargo area.



7. Securely store door to prevent damage to the door.

Suggested products:

- <https://www.extremeterrain.com/steinjager-portable-door-holder-0718-jk.html>
- <https://www.extremeterrain.com/lange-roof-panel-door-hanger-storage-combo-0717-jk.html>



8. Replace bezel for wiring harness on the interior of the door by placing it snugly where the brackets fit and pushing inwards.



9. Secure mirror arm from Round Adventure Mirror package by placing the lock and nut on the threads of the arm after placing the arm through the top external door bracket. Securely tighten nuts with a 15 mm socket.





10. Secure the mirror by unscrewing the 13 mm bolt from the back of the mirror, and then placing the bolt through the eye of the extending arm in the previous step. Tighten securely. Ensure that the mirror does not fall off of the arm before the bolt is securely placed on the mirror.



11. Repeat all previous steps on the passenger side of the vehicle. Adjust passenger mirror manually before driving.

12. Finished product





13. Tip: Keep your padded bags to store mirrors in Jeep when you are not using them!

Installation Instructions Written by ExtremeTerrain Customer Zack M. 25JUL18.