

## **Black Forest Gear Cargo Base Plate**

### **Installation Guide for Jeep Wrangler '07-'16 2-Door JK**

**Installation Time:** <1 Hour

**Tools Required:**

- ✓ Box Cutter/Knife
- ✓ Torx 30 Bit
- ✓ 10mm Socket
- ✓ Socket Wrench

**Installation Instructions:**

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Remove the backseat (Figure B).



Figure B

3. Install the supplied M6x25mm leveling feet on the bottom of the forward-most base plate (Figure C).



Figure C

4. Install the supplied M6x12mm leveling feet on the bottom of the rear-most base plate (Figure D).



Figure D

5. Mount the forward-most base plate at the rear-most seat bracket assembly using the supplied retainer tension bolts and a 10mm socket wrench (Figure E). Ensure the rubber tension bolt cap stays intact.



Figure E

6. Remove the rear-most tie downs using a Torx 30 bit (Figure F).



Figure F

7. Align the rear-most base plate bracket with the rear mounting holes and secure using the tie downs removed in Step 6 (Figure G).



Figure G



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 02/22/2018