

Boom Mat Sound Deadening Headliner - White
Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife (For Packaging)

Installation Instructions:

1. Remove the hard top from the vehicle (Figure A).



Figure A

2. Using alcohol and a cloth or paper towel, clean the entire interior surface where the headliners will be mounted (Figure B).



Figure B

3. Begin by removing the backing from the filler strips (Figure C).



Figure C

4. Place filler strips in the top hard top interior. Each filler strip is measured to fit the length of a groove in the interior of the hard top (Figure D).



Figure D

5. Place filler strips in the bottom of the hard top interior (Figure E).



Figure E

6. Place the bottom headliner in softly and gently press down to allow the headliner to adhere to the surface (Figure F).



Figure F

7. Next, remove the backing of the top panel and place it softly on the surface and gently press it into place, as well (Figure G).



Figure G

8. Place the filler strips inside the freedom top and remove the backing of the freedom top panel and place it softly on the surface, pressing gently to adhere it into place (Figure H).



Figure H

9. Allow the hard top pieces to sit for at least 30 minutes for full adhering of materials.



Before



After