

## **Installation Guide for RT Off-Road Black Bug Screen (97-06 Wrangler TJ)**

**Installation Time:** 20-25 Minutes

**Tools Required:**

- ✓ Tool 1- Power Drill
- ✓ Tool 2- Zip ties or Tape
- ✓ Tool 3- 1/8" Drill bit
- ✓ Tool 4- Phillips Head Drill bit
- ✓ Tool 5- Permanent Marker
- ✓ Tool 6- thread locker

**Installation Instructions:**

1. Instruction one:
  - Begin by either using zip ties or tape to align the Bug Screen to desired position.



2. Instruction two:

- Use a permanent marker to mark the location of where you want the 4 screws to be positioned on the jeep.



3. Instruction three:

- Remove Bug Screen from Jeep and begin by drilling the 4 screw locations with the 1/8" drill bit
  - **\*be aware of any objects behind the drilling locations as to prevent damage\***



4. Instruction four:

- Realign the Bug Screen in the desired position and apply Thread locker to the screws.
- begin installing the 4 provided screws into the holes drilled previously in step three.



5. Instruction five-

- Enjoy your newly installed Bug Screen and ensure all screws are tightened as to prevent them from falling out in the future.

