

RT Off-Road Combo Beach Topper - Black Denim (97-06 Wrangler TJ, Excluding Unlimited)

Installation Time: 60 Minutes

Tools Required:

✓ None

Windshield Header REQUIRED to complete installation. Show is the Smittybilt Windshield Header Item J16173 MPN# 90104

Installation Instructions:

1. Remove the factory soft top or hard top and install the windshield header



2. RT Off-Road Combo Beach Topper - Black Denim



3. Start by pressing in most of the front seam into the windshield header. It will not stay.



4. Using the supplied strap holders



5. Secure the rear two straps loosely to apply a little tension to the front seem. This will help to hold it in place.





6. Complete the front seam. Then use the side Velcro straps to work your way back.



7. When using the door surrounds clip the plastic portion into the channel just like the factory soft top.



8. The extra flap would be for an installation without door surrounds. They can just be tucked away.



9. Secure the two straps around the center roll bar



10. Secure the outer straps around the center roll bar





11. Snug the rear straps and installation is complete.





Installation Instructions Written by ExtremeTerrain Customer T. Boyer 4/10/2018