

Daystar Cam Can Complete Kit - Black - Non-Flammable Liquids

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Philips Head Screwdriver
- ✓ 13mm Wrench
- ✓ 8mm Socket
- ✓ 19mm Socket
- ✓ Socket Wrench
- ✓ Lug Wrench (optional)

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the entire kit is included and undamaged.



Figure A

2. Using a Philips head screwdriver and the supplied screws, install the mounting hardware onto the front of the can (Figure B).



Figure B

3. Using a Philips head screwdriver and the supplied screws, install the mounting hardware onto the rear of the can (Figure C).



Figure C

4. Install mounting brackets onto the mounting plate using an 8mm socket wrench and Philips head screwdriver, along with the supplied screws and nuts (Figure D).



Figure D

5. Attach the aluminum center pole to the mounting plate using the provided 19mm bolt and lock washer (Figure E).



Figure E

6. Using a 19mm socket wrench (or lug wrench) remove the three lugs holding the spare onto the rear of the vehicle (Figure F).



Figure F

7. Replace the lugs with the supplied stud extenders and tighten down using a 13mm wrench (Figure G).



Figure G

8. Place the mounting plate onto the stud extenders and secure using supplied 19mm nuts (Figure H).



Figure H

9. Slide the cam can onto the aluminum center pole, press in, and turn clockwise to lock into place (Figure I).



Figure I



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 12/13/2017