

Daystar Cam Can Complete Kit - Gray - Drinking Water

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 19mm Socket
- ✓ Socket Wrench
- ✓ Philips Head Screwdriver
- ✓ 8mm Box Wrench

Installation Instructions:

1. Set out the mounting plate (Figure A).



Figure A

2. Connect the mounting platform using the supplied screws and washers, as well as a Philips head screwdriver and an 8mm box wrench (Figure B).



Figure B

3. Repeat Step 2 for the other two mounting platform pieces (Figure C).



Figure C

4. Thread the long support rod into the center hole and tighten down the supplied bolt using a 19mm socket wrench (Figure D).



Figure D

5. Place the receiver end of the mounting platform onto the cam can (Figure E).



Figure E

6. Using the supplied screws and a Philips head screwdriver, connect the piece to the cam can (Figure F).



Figure F

7. Repeat Steps 5 and 6 for the other two pieces.
8. Flip the cam can over and place the remaining attachment pieces onto the cam can (Figure G).



Figure G

9. Using the supplied screws, attach each of the plastic pieces (Figure H).



Figure H

10. Remove the lug nuts from the spare tire using a 19mm socket wrench (Figure I).



Figure I

11. Thread all three extensions onto the bolt locations (Figure J).



Figure J

12. Connect the mounting platform and tighten down the supplied nuts (Figure K).



Figure K

13. Place the cam can on and lock into place.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 07/01/2018