

Drake Off Road Fire Extinguisher Mount

Installation Time: 15 Minutes

Tools Required:

- ✓ 11 mm socket

Installation Instructions:

1. 2 3/4 " hose clamps for mounting the fire extinguisher to the Drake mount



2. I used a 1.25 LB fire extinguisher



3. Place the fire extinguisher in the correct orientation for your mounting location



5. Both clamps installed



6. I chose to install it between the front seats on the top roll bar



7. Using the Drake Off Road Fire Extinguisher Mount Clamps – Small Item J102670



8. Use a 11 mm socket to snug up the clamp to hold the mount in place



9. After snugging the first clamp with the correct orientation, install the 2nd clamp





10. Pull the red knob to release the fire extinguisher



11. Slide the rear in first then the front will snap in



12. Installation complete



Installation Instructions Written by ExtremeTerrain Customer T. Boyer 4/16/2018