

Drake Off Road Fire Extinguisher Mount Clamps - Small

Installation Time: 15 Minutes

Tools Required:

- ✓ 11 mm socket

The Item J102670 came with 4 clamps. I am not sure if this would be Small and large. They where two different sizes.

Installation Instructions:

1. Clamps received with Item J102670



2. I used the larger of the two clamps to mount the Drake Off Road Fire Extinguisher Mount Item J17982

3. I chose to mount the Fire Extinguisher above the front seats



4. Slide one of the clamps around the roll bar



5. Use a 11 mm socket to snug up the clamp to hold the mount in place



6. After snugging the first clamp with the correct orientation, install the 2nd clamp





7. Installation complete

