

DV8 Off-Road FS-17 Front Bumper Install Guide

Installation Time: 30 Minutes

Tools Required:

- ✓ ½" Drive Ratchet
- ✓ 18 MM Socket
- ✓ 16 MM Socket
- ✓ Flat head screwdriver
- ✓ Phillips head screwdriver

Installation Notes, Pre-Installation notes (only when needed)

Installation Instructions:

1. Disconnect and remove fog lights from the stock bumper.



2. Using a Philips head and flat head screw driver remove the upper and lower plastic gap covers.



- Using an 18MM socket, remove (8) body bolts from the stock bumper.



- Carefully remove OEM bumper from the front of the vehicle.
- Carefully place DV8 front bumper onto stock threads. (May need another pair of hands for this step)
- Using a 16MM socket, begin bolting new bumper into existing threads using provided hardware. (6 nuts, washers, and lock washers. 2 bolts, lock washers, and washers.)
- Reconnect fog lights or accessories and admire your new bumper.



Seth Moore
Order #: 13549567
DV8 Off-Road FS-17 Front Bumper

