

DV8 Off-Road Hood Light Bar Mounting Bracket - Installation Guide

Installation Time: 20 Minutes

Tools Required:

- ✓ Ratchet with TORX T50 Socket
- ✓ Utility Knife (Razor Blade) to open the product shipping box

There is a total of 1 part. 1 – Hood Light Bar Mounting Bracket



Note: This Installation guide is to show you how to install the DV8 Off-Road Hood Light Bar Mounting Bracket only.

Before Install



Installation Instructions:

1. Remove two (2) TORX T50 bolts from the hood bracket on the driver and passenger side. Keep these bolts as you will reuse them.

Note: Do Not open your hood with these bolts removed.



2. Place the Hood Light Bar Mounting Bracket on the hood brackets. Place two (2) TORX T50 bolts on one side and then two (2) on the opposite side.



3. Tighten all four (4) TORX T50 bolts securing the Hood Light Bar Mounting Bracket to the hood.



Note: Depending on your TORX T50 socket you may need to use an extension to secure the bolt that is closest to the metal bar of the bracket as shown below.





After Install



Installation Instructions Written by ExtremeTerrain Customer Brian Voelzke 07/08/2018