

DV8 Off-Road Taillights

Installation Time: 15 Minutes

Tools Required:

- ✓ Phillips head screw driver
- ✓ Electrical connector grease

Suggestion: Keep stock lights for spares.

Installation Instructions:

1. Remove the 2 inner Phillips head screws.



2. Unplug the electrical connector from the stock taillight.



3. Plug in the connector to the new DV8 Off-road Taillights.



4. Place new DV8 Off-road Taillights appropriately and screw back in using stock Phillips head screws.



5. Check that brake, taillight, running light, and reverse lights are in working order.