

## GraBars BootBars Foot Pegs - Black (87-06 Wrangler TJ & YJ)

**Installation Time:** 30 Minutes

**Tools Required:**

- ✓ 14mm socket or box end wrench
- ✓ 8mm Allen

*The hardware provided was very oddly sized. The above tools were what I found to work. They did not fit as I would have liked on the hardware. For that reason I will be purchasing new hardware to make the removal and reinstallation smoother.*

**Installation Instructions:**

1. Before foot peg installation, remove the door



2. Parts provided with the GraBars BootBars Foot Pegs



3. Per side one 8mm allen bolt, 2 washers and one 14mm nut



4. The bolt head will be recessed into the foot peg. Driver side shown



5. Insert the bolt then one washer, insert the bolt into the hinge finish off with one washer and then the nut.



6. Tighten hardware and installation is complete. Passenger side shown

