

GraBars Front Grab Handles w/ Green Grips
Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: <1 Hour

Tools Required:

- ✓ 13mm Socket
- ✓ Socket Wrench
- ✓ 6mm Allen Wrench

Installation Instructions:

1. Locate the two inner bolts at the top corner of the passenger's door frame (Figure A).



Figure A

2. Using a 13mm socket wrench, remove the lower of the two corner bolts (Figure B).



Figure B

3. Using a 13mm socket wrench, remove the upper of the two corner bolts (Figure C).



Figure C

4. Place the shorter of the two bolts through the passenger-side Grabar (Figure D).



Figure D

5. Set the shorter spacer on top of the passenger Grabar (Figure E).



Figure E

6. Hand-thread the bolt into the top hole of the two bolts removed (Figure F).



Figure F

7. Slide the longer spacer in between the Grabar and the frame and insert the longer bolt (Figure G).



Figure G

8. Using a 6mm Allen wrench, tighten the bolts into place (Figure H).



Figure H

9. Repeat Steps 1-8 on the driver's side.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 08/19/2018