

Iron Cross Front Fender Flares - Black

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 10mm Socket
- ✓ Socket Wrench
- ✓ 10mm Wrench

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Find the corner of the existing fender flares (Figure B).



Figure B

3. Using moderate force, pull directly backward and the clips holding the fender in place should release (Figure C).



Figure C

4. Once all the clips are pulled clear, remove the fender and set aside (Figure D).



Figure D

5. Run the protective cornering along the inward edge of the Iron Cross fender flare, ensuring the longer side is on top (Figure E).



Figure E

- Place the Iron Cross fender flare in place on the vehicle and hand tighten the supplied bolts, washers, and nuts to keep the fender flare in place (Figure F).



Figure F

- With the Iron Cross fender flare in place, tighten all bolts using a 10mm socket wrench and a 10mm wrench (Figure G).



Figure G

8. Once the Iron Cross fender flares are secured completely, remove the red adhesive cover along the line and press down with moderate pressure (Figure H).



Figure H

9. Repeat Steps 2-8 on the other side.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 04/26/2018