

Installation Instructions for J TopsUSA Tube Soft Top Window and Gear Storage (J104814)

Installation Time: 10 Minutes or less

Tools Required:

- ✓ None

To keep your windows from getting scratched leave them on your Jeep until the tube is unrolled and you are ready to place them in the tube.

Installation Instructions:

1. Place tube on the ground with enough space around to fully unroll it (Approx. 10 feet)



2. While tube is still rolled remove end plug by turning wing nut counter clockwise.



3. Remove rear window bar before removing rear window from Jeep.



4. Slide window bar into tube.



5. Reinstall end plug and tighten wingnut.

6. Unlock straps and stretch them out.



7. Unroll tube. You will see that there are three inner layers of protective fabric.



8. Fold top two layers of fabric toward tube.



9. Place rear window with bottom toward tube and inside facing up. Make sure window plastic is on fabric.



10. Cover rear window with one layer of protective cloth.



11. Place side windows on top of rear window inside facing up. Make sure the door edge of the window is toward the tube.



12. Cover side windows with last layer of protective cloth.



13. With windows in place and all layers of protective cloth covering the plastic roll tube toward straps. It is not necessary roll really tight but let the tube do the work for you. Smooth the fabrics layers as you roll.



14. Pull straps around rolled tube.



15. Buckle straps pull tight and engage locks.



16. Tube stores behind the rear seat and can be loaded from the side or the rear.



17. It sits on the depressions in the fender wells (JKU) and as you see there is room underneath for additional storage. (To keep it safe I use a cable lock to prevent snatch and grab theft.)

