

## J Tops USA Tonneau Cover - Black

### Installation Guide for Jeep Wrangler '07-'16 2-Door JK

**Installation Time:** <1 Hour

**Tools Required:**

- ✓ Box Cutter/Knife

**Installation Instructions:**

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the cover is included and undamaged.



Figure A

2. Lay the cover out in the sun to heat the material before attempting to put on (Figure B).



Figure B

3. Place the cover inside the cab of the vehicle as it will be installed (Figure C).



Figure C



- Slide the front piece over the lip of the outer cab (Figure D).



Figure D

- Slide the rear piece over the lip of the outer cab (Figure E).



Figure E

- Do so on the other side of the cab, as well.

7. Pull the magnetic rear along the rear hatch (Figure F).



Figure F

8. Press the magnetic rear strip along the rear and pull tight (Figure G).



Figure G





Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 04/18/2018