

J Tops USA Tonneau Cover - Black (07-17 Wrangler JK 4 Door) Installation Guide

Installation Time: 15 Minutes

Tools Required:

✓ None

Installation Instructions:

1. Remove Hard Top



2. Take corner of Tonneau Cover and slip the white tabs under the lip



3. Repeat for opposite side



4. Attach the metal hook that is not attached to the bungee strap under the lip



5. Slip the long white tab under the lip



6. Take the metal hook attached to the bungee strap and slide it under the lip



7. Slip the long white tab under the lip



8. Attach the magnets to the tailgate



9. Finished



Installation Instructions Written by ExtremeTerrain Customer Thomas Sandoval 06/15/2017