

KC HiLiTES 2 in. C-Series C2 LED Light Bar - Flood Beam

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: <1 Hour

Tools Required:

- ✓ Allen Wrench
- ✓ 10mm Socket Wrench
- ✓ 13mm Socket Wrench
- ✓ Light Wiring Harness

Installation Instructions:

1. Place the mounting hardware out next to the LED (Figure A).



Figure A

2. Insert the bolt with the square centering into the metal mounting piece before placing the mount on the LED (Figure B).



Figure B

3. Align the metal mounting piece with the LED mounting holes (Figure C).



Figure C

4. Run the smaller bolt through the holes (Figure D).



Figure D

5. With the smaller bolt all the way through, thread the smaller washer to hold it in place (Figure E).



Figure E

6. Using an Allen wrench and 10mm socket wrench, tighten the washer down so that the metal mounting piece is secured into place (Figure F).



Figure F

7. Slide a flat washer over the mounting bolt (Figure G). Then, using a 13mm socket wrench, tighten the bolt onto the desired LED mounting location.



Figure G

8. Connect the LED to a light wiring harness (not provided) to provide power.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 09/26/2018