

Omix-ADA Fender Flares

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 10mm Socket
- ✓ Socket Wrench
- ✓ Fender Flare Hardware Kit (not included)

Installation Instructions:

1. Begin by removing the current fender flare from the vehicle using a 10mm socket wrench (Figure A).



Figure A

2. Once all bolts have been removed, pull the current fender flare away from the vehicle (Figure B).



Figure B

3. Remove the Omix-ADA fender flare from the box and set them upside down on a soft surface. Locate the notched openings (Figure C).



Figure C

4. Using pop-ins from a fender flare hardware kit (not included), slide pop-ins over the openings along the inside of the fender flares (Figure D).



Figure D

5. Once the pop-ins are slid into place, press down to secure each clip flat with the inside of the fender flare (Figure E).



Figure E

6. Line up the pop-ins with the fender flare holes on the vehicle and press them in (Figure F).



Figure F

7. Take the factory turn signal and move it into the hole of the fender flare (Figure G).



Figure G

8. Repeat Steps 1-7 on the other side of the vehicle.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 06/28/2018