

Omix-ADA Turn Signal Parking Lamp Assembly Installtion Guide

Installation Time: 30 Minutes

Tools Required:

- ✓ T10 star bit

Installation Instructions:

1. Before, the lights where fogged and showed slight cracks.



2. Remove 2 factory T10 star screws



3. Pull the original Turn Signal Parking Lamp Assembly out of the fender.



4. While grabbing the Turn Signal Parking Lamp Assembly with one hand and the light socket with another rotate counter clock wise, 1 half turn.



5. While grabbing the new Omix-ADA Turn Signal Parking Lamp Assembly with one hand and the light socket with another rotate clock wise, 1 half turn.



6. When reinstalling the new Omix-ADA Turn Signal Parking Lamp Assembly line up the pins located on the Omix-ADA Turn Signal Parking Lamp Assembly with the cut outs in the fender.



7. Reinstall the 2 factory T10 star screws, installation complete



Installation Instructions Written by ExtremeTerrain Customer T. Boyer 10/19/2017