Raxiom 50 in. Straight Dual Row LED Light Bar - Flood/Spot Combo Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter or Knife
- ✓ Crimp Tool or Pliers
- ✓ Electrical Tape
- ✓ Wire Connectors
- ✓ Wiring Harness
- ✓ Switch
- ✓ Light Bar Mount

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the light bar is included and undamaged.



Figure A

- 2. Mount to an A-pillar light mount for 50" light bars (not supplied) using supplied bolts and washers.
- 3. Run wires from a wiring harness (not supplied) through to the top of the A-pillar light mount (Figure B). **Note:** Either purchase the wiring harness from the same supplier as the light bar for a quick connection or create a wiring harness using 14-16 gauge wires.



Figure B

4. Connect wires from the light bar to the wiring harness using wire connectors and electrical tape (not supplied) (Figure C).



Figure C

5. Connect the relay wire from the wiring harness to the switch (not supplied) (Figure D).



Figure D

6. Connect the light bar wire from the wiring harness to the switch (Figure E).



Figure E

7. Connect the ground to the switch and connect to the chassis of the vehicle (Figure F).



Figure F



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 10/21/2017