

## Recon Side Marker Lights w/ Amber LEDs (07-17 Wrangler JK) Installation Guide

**Installation Time:** 30 Minutes

**Tools Required:**

- ✓ Center Punch (OR something thin and strong)

**Installation Instructions:**

1. Unplug the light harness.



2. Remove the light by twisting it out of the light assembly.



3. Remove the light from the plastic piece it is in by pulling it out.



4. Attach the plastic piece to the Recon light assembly.



5. Plug the light into the harness and see if it is working correctly.



6. Using something long and thin, punch out this thing holding the fender and the inner fender liner together. (I used a T10 Torx bit on my screwdriver.)



7. Remove the light assembly.



8. Unplug the Recon light and insert it into the fender.



9. Plug the light assembly back in making sure it is plugged in, in the correct direction and working. Re-install the things taken off the fender in step 6.



10. Repeat for opposite side



Installation Instructions Written by ExtremeTerrain Customer Thomas Sandoval 06/15/2017