

## RedRock 4x4 Dead Pedal - Driver Side

### Installation Guide for Jeep Wrangler '07-'16 2-Door JK

**Installation Time:** <1 Hour

**Tools Required:**

- ✓ Box Cutter/Knife
- ✓ 10mm Socket
- ✓ Socket Wrench

**Installation Instructions:**

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Disconnect the electrical plug on the interior of the driver's side (Figure B).



Figure B

3. Unhook the strap from the metal hook (Figure C).



Figure C

4. With the strap and electrical wiring out of the way, locate the door strap metal hook and remove the two bolts using a 10mm socket wrench (Figure D).



Figure D

5. Locate the two electrical ground nuts near the metal hook bolts and remove the two bolts using a 10mm socket wrench (Figure E).



Figure E

6. Place the mounting side of the dead pedal along the inner side, aligning with the holes of the removed bolts (Figure F).



Figure F

- Return the two metal hook bolts (Figure G) and tighten using a 10mm socket wrench.



Figure G

- Return the two electrical ground nuts (Figure H) and tighten using a 10mm socket wrench (Figure H).



Figure H

9. Reconnect the door strap to the metal hook (Figure I) and reconnect the electrical connection inside the door (Figure J).



Figure I



Figure J



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 04/01/2018