

REDROCK^{4X4}

2007-2017 JK Wrangler Hard Top Sound Deadener Kit



Step 1\\

Apply the 3M Hook and Loop to the back side of the front sound panels as seen above.



Step 2\\

Apply the 3M Hook and Loop to the back side of the rear sound panels as seen above.



Step 3\\

Thoroughly clean the inner hardtop panels of any dirt/grease. **Recommended: Wipe the hardtop panels down with isopropyl alcohol to ensure the cleanest surface possible. Allow the hardtop to dry prior to installing the trim pieces.



Step 4\\

Familiarize yourself with how the sound panel fits prior to peeling off the tape backing. Then remove the tape backing and apply firm even pressure to ensure proper adhesion.