

RedRock 4x4 Spare Tire Off-Road Light Mount Bracket

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 19mm Wrench
- ✓ 7/8" Socket
- ✓ Socket Wrench

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Using a 19mm wrench (or lug nut wrench), loosen the top two lug nuts of the spare tire (Figure B).



Figure B

3. Remove the top two lug nuts (Figure C).



Figure C

4. Place the two supplied lug nut extensions with the grip sides pointing in toward the spare tire (Figure D).



Figure D

5. Tighten each extension using a 19mm wrench (Figure E).



Figure E

6. Align the mount with the two extensions (mount can be facing up or down as long as light-mounts are facing away from the spare) (Figure F).



Figure F

7. Tighten each bolt (supplied) into the extensions using a 7/8" socket wrench (Figure G).



Figure G

8. Ensure the mount is secure (Figure H).



Figure H



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 05/30/2018