

Rigid Industries D-Series LED Cube Lights - Flood Beam - Pair

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Allen Wrench

Installation Instructions:

1. Connect the wiring harness by running the negative wire to the negative battery terminal (Figure A).



Figure A

2. Connect the wiring harness by running the positive wire to the positive battery terminal (Figure B).



Figure B

3. Run the wiring harness to the switch location and connect the black wire to the top terminal of the supplied Rigid switch (Figure C).



Figure C

4. Connect the red and black wire to the middle switch terminal (Figure D).



Figure D

5. Connect the red wire to the bottom switch terminal (Figure E).



Figure E

If using a normal light mount:

6. Place a supplied nut inside the mount bolt location (Figure F).



Figure F

7. Thread the bolt into the nut with the adjustable mounting piece in place (Figure G).



Figure G

8. Repeat Steps 6 and 7 on the other side.

9. Tighten the bolts down (Figure H).



Figure H

10. Utilize the bolt to connect to a traditional lighting mount (Figure I).



Figure I

11. Repeat Steps 6-10 on the other light.

If using a light side-mount:

12. Run the wiring harness connectors to the light mounting location (Figure J).



Figure J

13. Connect the light to the light mount (Figure K).



Figure K

14. Repeat Steps 12 and 13 on the other light.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 08/05/2018