

Rigid Industries D-Series Midnight Edition LED Cube Lights - Spot Beam - Pair

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife (Packaging)
- ✓ Allen Wrench
- ✓ 10mm Socket Wrench (Battery Terminal)
- ✓ 13mm Socket Wrench

Installation Instructions:

1. Locate the wiring harness (provided) and attach the negative (black) wire to the negative (-) battery terminal (Figure A).



Figure A

2. Attach the positive (red) wire to the positive (+) battery terminal (Figure B).



Figure B

3. Run the wiring harness into the cab and attach the wiring harness to the switch (Figure C).



Figure C

4. Move the light mount into place. Slide one of the two provided nuts into the indentation on the underside of one LED light (Figure D).



Figure D

5. Insert the bolt through the light mount and into the nut (Figure E).



Figure E

6. Using an Allen wrench (not provided) tighten the bolt down (Figure F).



Figure F

7. Repeat Steps 5 & 6 on the other side of the LED light.
8. With the light mount attached, insert the largest provided bolt with the square hold into the light mount and include the flat and locking washer on the other end (Figure G).



Figure G

9. Run the wiring harness ends to the desired light mounting location and attach the LED to the wiring harness (Figure H).



Figure H

10. With the bolt run through the LED mount (not provided), secure using the provided nut and tighten down with a 13mm socket wrench.
11. Repeat Steps 4-10 on the other LED light.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 10/04/2018