

## Rigid Industries Ignite Surface Mount LED Light - Flood Beam

### Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

**Installation Time:** <1 Hour

**Tools Required:**

- ✓ Allen Wrench
- ✓ Wiring Harness

**Installation Instructions:**

1. Align the Surface Mount LED Light to the GoPro mount (not included) (Figure A).



Figure A

2. Press firmly until the two mount extensions from the LED Light are fully flush with the three GoPro mount extensions (Figure B).



Figure B

3. Thread the GoPro mount screw in and ensure it runs through all five holes (Figure C).



Figure C

4. Tighten the GoPro screw down to secure the LED Light to the GoPro mount (Figure D).



Figure D

5. Connect a light harness end (not supplied) to the LED Light's black and red (negative and positive) wires (Figure E).



Figure E

6. Run the wiring harness (not supplied) to the battery, switch, and LED Light mounting location(Figure F).



Figure F

7. Connect the light harness end to the wiring harness (Figure G).



Figure G



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 09/14/2018