

Rigid Industries Dual D-Series A-Pillar Light Mount Kit

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Torx 40 Bit
- ✓ 5mm Allen Wrench

Installation Instructions:

1. Unscrew the front two A-Pillar factory bolts using a Torx 40 bit (Figure A). Then remove both bolts.



Figure A

2. Align one of the A-Pillar mounts with the two holes (Figure CB.



Figure B

3. Replace the bolts removed in Step 3 with the supplied bolts using a 5mm Allen wrench (Figure C).



Figure C

4. Place an LED in the bottom mount spacer (Figure D).



Figure D

5. Tighten a bolt (not supplied) into both sides (Figure E).



Figure E

6. Place an LED in the top mount spacer (Figure F).



Figure F

7. Tighten a bolt (not supplied) into both sides (Figure G).



Figure G

8. Repeat Steps 2-9 on the other side of the vehicle.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 06/13/2018