

Rugged Ridge 13 in. Reflex Stubby Antenna (97-06 Wrangler TJ)

Installation Time: 30 Minutes

Tools Required:

- ✓ 3/8 Wrench

Installation Instructions:

1. Before, the metal factory antenna would hit my LED cubes and make noise.



2. Use a 3/8 wrench to remove the factory antenna.



3. Inspect the threads and possibly apply anti-seize





4. After removing the factory antenna I observed that the new Rugged Ridge 13 in. Reflex Stubby has a longer threaded shaft than the factory antenna.





5. Use your hands to tighten the new Rugged Ridge 13 in. Reflex Stubby Antenna. It may have a gape due to the threaded shaft on the Rugged Ridge 13 in. Reflex Stubby Antenna being longer than the factory.



6. Installation complete



Installation Instructions Written by ExtremeTerrain Customer T. Boyer 11/03/2017