

Rugged Ridge Eclipse Cargo Barrier

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓

Installation Instructions:

1. Remove the hard top from the vehicle or lower the soft top (Figure A).



Figure A

2. Lay the cargo barrier over the rear of the vehicle, plastic hooks at the bottom (Figure B).



Figure B

3. Run one of the two top elastic cords around the rear roll bar (Figure C).



Figure C

4. Slide the plastic notch through the elastic cord loop (Figure D).



Figure D

5. Repeat Steps 3 and 4 on the other side (Figure E).



Figure E

6. Connect each of the four side straps using the same method as Steps 3 and 4 (Figure F).



Figure F

7. Slide each of the plastic hooks over the tub lip on the rear side of the vehicle (Figure G).



Figure G

8. Connect the top of one of the side barriers using the same procedure as Steps 3 and 4 (Figure H).



Figure H

9. Place the bottom hooks in the corresponding holes (Figure I).



Figure I

10. Repeat Steps 8 and 9 on the other side (Figure J).



Figure J



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 07/01/2018