

# Rugged Ridge Gray Vinyl Water Resistant Cab Cover

## Installation Guide

**Installation Time:** 30 Minutes

**Tools Required:**

- ✓ Scissors

*This guide will not cover how to lower the soft-top/remove the soft-top hardware, nor how to remove the doors for the vehicle. The cover fits best with the soft-top removed (not stowed), but will function adequately with the soft-top just stowed.*

**Installation Instructions:**

1. Prepare your Jeep for installation by removing/stowing the soft-top and optionally removing all doors.



2. Open the packaging with scissors and remove the cover as well as provided cover storage bag





3. Place cover over the vehicle such that the doors are covered; try to center the cover properly before beginning to attach it to the frame to prevent mis-alignment



4. Insert the plastic lip of the cover into lip in the rear of the vehicle where the soft-top connects as shown below.





5. Attach the two plastic clips at the rear of the cover to the underside of the back door.
6. Attach the plastic 3 clips on either side of the cover to the underside of the frame.
7. Tighten all clips.

