

Rugged Ridge Lower Switch Panel Kit (07-10 Wrangler JK w/ Automatic Transmission) Installation Guide

Installation Time: 30 Minutes

Tools Required:

- ✓ Sharp Knife
- ✓ Pliers

Installation Instructions:

1. Pop off the lower panel.



2. Cut a hole in the lower switch panel for the switch of your choice.



3. Insert the rocker switch into the hole you just cut.



4. Take the two retaining clips off of the lower panel and place them onto the lower switch panel. This may require the use of pliers.
5. Wire to the Rugged Ridge rocker switch. Top is ground, middle is the power to the positive end of the battery, bottom is to the negative end of the battery.



6. Align the lower switch panel, making sure none of the wires will be in the way.



7. Re-insert the lower switch panel making sure there is a tight fit.



Installation Instructions Written by ExtremeTerrain Customer Thomas Sandoval 06/07/2017