

Rugged Ridge No Drill Windshield Channel (97-06 Wrangler TJ)

Installation Time: 15 Minutes

Tools Required:

- ✓ ½ socket

Installation Instructions:

1. With the soft top or hard top removed



2. Locate the provided hardware



3. Lay the Rugged Ridge No Drill Windshield Channel on top of the windshield. While lining up the cutouts.



4. Insert the ½ bolts



5. Snug the bolts down. The header will lean towards the rear of the jeep. Installation complete



Installation Instructions Written by ExtremeTerrain Customer T. Boyer 4/10/2018