

Skid Row Off-Road Foot Pegs (2018 Wrangler JL) Installation Guide

Installation Time: 5 Minutes

Tools Required:

✓ None

Included Components:



Installation Instructions:

1. Slip the vinyl caps onto the tab on each of the foot pegs.



2. After removing your Jeep's doors, place each foot peg into the lower hinge on each side.



3. Put one of the hairpin cotter pins through the hole below the hinge.



Before



After



Installation Instructions Written by ExtremeTerrain Customer Zac Hart 08/03/2018