

Smittybilt Atlas Door Step

Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ 50 Torx Bit

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Using a 50 torx bit, remove the bottom bolt of the door hinge.
3. Remove the door from the hinge (Figure B).



Figure B

4. Using a 50 torx bit, remove the top two hinge bolts (Figure C).



Figure C

5. Using a 50 torx bit, remove the bottom two hinge bolts (Figure D).



Figure D

6. Place the Smittybilt Atlas Door Step over the hinges, aligning the holes.
7. Using a 50 torx bit, replace the top two hinge bolts (Figure E).



Figure E

8. Using a 50 torx bit, replace the bottom two hinge bolts (Figure F).



Figure F

9. Tighten all bolts (Figure G). Return the door onto the vehicle door hinge.



Figure G

10. Return the bolt removed in Step 2.

11. Repeat Steps 2-10 on the other door.



Before



After

Installation Instructions Written by Extreme Terrain Customer J. Sandlin 03/01/2018