

Smittybilt Outback Wind Breaker - Black Diamond
Installation Guide for Jeep Wrangler '07-'16 2-Door JK

Installation Time: <1 Hour

Tools Required:

- ✓ Box Cutter/Knife

Installation Instructions:

1. Carefully open the package using a box cutter or knife (Figure A) and ensure the hardware is included and undamaged.



Figure A

2. Layout the wind breaker so the fabric can heat up (Figure B).



Figure B

3. Run the fabric straps over the sport bar and through the buckle (Figure C).



Figure C

4. Loop the fabric strap around the top of the side of the sport bar on both sides (Figure D).



Figure D

5. Loop the fabric strap around the bottom of the side of the sport bar on both sides (Figure E).



Figure E

6. Run the fabric strap over the upper corner of the sports bar on both sides (Figure F).



Figure F

7. Loop the two fabric straps through the front seat risers on both sides (Figure G).



Figure G



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 04/26/2018