

Installation of Snyder LED Light Pillar Mounting Brackets

Installation Time: 15 Minutes

Tools Required:

- ✓ 3/8" Ratchet
- ✓ Torx T40 socket
- ✓ Supplied M8 Allen Key
- ✓ Utility Knife
- ✓ Torque Wrench

Cleaning solution and a cloth may be utilized if desired.

Installation Instructions:

1. Locate and line up A-pillar gasket on backside of the mounting bracket. Pull off backing material and stick to the new bracket





2. Locate and remove 5 T40 bolts in the bottom of the A pillar. Do not remove the bottom bolt unless cleaning under is desired.



3. Remove bottom bolt if cleaning is desired to prevent build-up and rusting



4. Cut holes in the A-pillar gasket to allow insertion of the new bolts



5. Align and install mounting bracket using the supplied M8 hex head cap screws and washers. Tighten to 15 ft-lbs. using torque wrench



Before

After

