

Terraflex Roll Bar Grab Handles (87-18 Wrangler YJ, TJ, JK)

Installation Time: 10 Minutes

Tools Required:

None

This installation was conducted on a 2005 Jeep Wrangler Unlimited. For better visibility the sunrider top has been folded back but the handles can be installed with the top in place.

You will receive 2 grab handles as shown below.



Installation Instructions:

1. Pick the desired location for the handle. In this guide it is being installed on the roll bar above the passenger door.



2. Lay the straps over the roll bar so that the handle is toward the inside of the vehicle and the Velcro on the free ends of the straps faces out. On this Jeep the straps are placed between the roll bar and the door surround so that they do not interfere with the top.



3. Feed the straps through the buckles and back up and over the roll bar. Pull tight.





4. Continue to wrap straps around the roll bar from top to bottom. Pull tight and Velcro in place.



5. Tuck any extra strap out of they way as needed. Repeat with second handle.



Installation Instructions Written by ExtremeTerrain Customer Jason Horn 1/21/2018