

Teraflex Sport Front Lower FlexArm Kit
Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Jack
- ✓ Crescent Wrench
- ✓ 21mm Socket Wrench
- ✓ Torque Wrench

Installation Instructions:

1. Raise the front end of the vehicle and remove the front tires.
2. Loosen the top part of the lower control arm on the driver's side using a 21mm socket wrench (Figure A).



Figure A

3. Loosen the lower part of the lower control arm on the driver's side using a 21mm socket wrench (Figure B).



Figure B

4. Remove both bolts and set the lower control arm to the side (Figure C).



Figure C

5. Set the TeraFlex front lower control arm into place and tighten slightly (Figure D).



Figure D

6. Place the bolt through the other end of the front lower control arm (Figure E).



Figure E

7. Tighten bolts further (but not fully torqued) (Figure F).



Figure F

8. Repeat Steps 2-7 on the passenger's side.
9. Return the front tires and lower the jack.
10. Torque each of the bolts to 125 ft. lbs.



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 11/11/2018