

Teraflex Sport Rear Lower FlexArm Kit for 2.5-3 in. Lift

Installation Guide for Jeep Wrangler '07-'18 4-Door JKU

Installation Time: 1 Hour

Tools Required:

- ✓ Box Cutter/Knife
- ✓ Jack
- ✓ Jack Stands
- ✓ Crescent Wrench
- ✓ 21mm Socket Wrench
- ✓ Torque Wrench

Installation Instructions:

1. Jack up the rear end of the vehicle at the axle.
2. Place the vehicle on jack stands (Figure A).



Figure A

3. Remove both of the tires.
4. Relax the top bolt of the driver's side rear lower control arm using a 21mm socket wrench (Figure B).



Figure B

5. Relax the bottom bolt of the rear lower control arm using a 21mm socket wrench and crescent wrench (Figure C).



Figure C

6. Remove the bolts and set the old control arm aside (Figure D).



Figure D

7. Put the TeraFlex rear lower control arm into place and run the bolt through the top end (Figure E).



Figure E

8. Tighten the bolt using the captured nut and a 21mm socket wrench (Figure F).



Figure F

9. Run the bolt through the bottom end (Figure G).



Figure G



Before



After

Installation Instructions Written by ExtremeTerrain Customer J. Sandlin 11/11/2018