

INSTALLATION INSTRUCTIONS

Left Side Replacement Mirror - Textured Black (07-16 Wrangler JK)

Installation Time: 30 Minutes

Tools Required:



- ✓ 3/8" Ratchet
- ✓ T40 Torx bit or 13 mm Sockets

Installation Instructions:

1. If you're replacing a broken factory mirror, remove the (2) T40 Torx head bolts securing the old mirror to the factory door. If your Jeep is 2011+, it might come equipped with a power/heated mirror, requiring you to unplug the factory harness, once the broken mirror has been removed.



2. Insert the appropriate side, replacement mirror into position. The photo below illustrates the mirror mounted to an aftermarket Tube Door, this highlights the mounting stems that would not be seen in a factory door installation. **Note:** if the Jeep is equipped with wiring for the mirror, attach the factory wiring before inserting into position.



3. If the replacement mirror is mounted to the factory door, secure into position with the factory T40 Torx bolts. If the mirrors are installed on Tube Doors, use the supplied hardware from the kit to secure into position.



4. Installation is complete.



Installation Instructions Written by ExtremeTerrain Customer Louis Orellana 05/24/2016