



## Barricade Trail Force HD Rear Bumper (07-18 JK)

### Contents:

- (1) Rear Bumper
- (2) Frame Rail Brackets
- (4) M12 x 1.75 x 120mm Bolts
- (4) M12 x 1.75 x 40mm Bolts
- (12) M12 Flat Washers
- (8) M12 Lock Washers

- (4) M12 Nuts
- (2) D-Rings

### TOOLS REQUIRED:

- 15mm, and 18mm Sockets
- T55 Torx Bit
- Ratchet
- Clean Towel
- Cleaning Solution



**STEP 1** // Remove the (4) 15mm bolts on the outside of each frame rail. Then remove the (4) 15mm bolts securing the plastic bumper to the frame. Remove the bumper.



**STEP 3** // Insert the (2) frame rail brackets into the frame rails. \*\*Note be sure that the holes from the frame rail line up with the bracket holes.



**STEP 2** // Remove the (3) 15mm bolts securing the tow hook to the driver side frame rail.



**STEP 4** // Install the new Barricade bumper to frame rails using the (2) M12 x 40mm bolts, flat washers, and lock washers. Torque to 40 ft - lbs.



**STEP 5** // From under the vehicle, install the (1) Tow Hitch to the frame using the (4) M12 x 120mm bolts, flat washers, lock washers, and nuts. Torque to 40 ft - lbs.



**STEP 6** // Insert the (2) D-Rings if desired. Installation is now complete.