



REAR FENDERS

(1997-2006 Wrangler TJ)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) - Left Side Fender
- (1) - Right Side Fender

TOOLS REQUIRED

- 8mm Socket
- Socket Wrench
- Adjustable Wrench
- Pliers

STEP 1

Pull back the fender liner from the lip of the fender. Squeeze the well liner retainer tab and push it back through the fender. Remove any other hardware holding the wheel well liner in place.

STEP 2

Remove the (8) 8mm screws holding the fender flare to the body. 6 of the 8 bolts are secured with a square plastic nut on the inside of the body panel. Use an adjustable wrench to secure the square nut while removing the (6) 8mm screws. The front (2) screws thread into the body.

**STEP 3**

Reinstall (6) of the (8) 8mm screws that were removed. 5 of the 6 plastic nuts will be reused and 1 screw will thread into the body. Repeat these steps for the opposite side.